Warwick Cove



Warwick Cove Federal Transient Anchorage Area	
No.	State Plane Coordinates
A	N 218945.00, E 529620.00
B	N 218945.00, E 529162.35
C	N 219340.00, E 529162.35
D	N 219439.65, E 529335.76

Warwick Cove Federal Mooring Area No. 1	
No.	State Plane Coordinates
E	N 221098.87, E 529511.44
F	N 220900.10, E 529393.44
G	N 220808.28, E 529375.89
H	N 220322.23, E 529454.85
I	N 220115.33, E 529305.69
J	N 220671.26, E 529215.37
K	N 220855.90, E 529250.47
L	N 221199.63, E 529455.04

Warwick Cove Index of Navigation Aids (Buoys)	
No.	State Plane Coordinates
C-1	N 216402.90, E 529306.10
N-2	N 216488.00, E 529436.40
C-3	N 218054.60, E 529329.30
N-4	N 218013.70, E 529438.20
C-5	N 218604.40, E 529628.00
C-7	N 218960.70, E 529635.60
C-9	N 220834.40, E 529121.40
N-10	N 222428.00, E 529999.90
N-12	N 222833.70, E 529997.20

LEGEND

- DOCKS AND SLIPS
- MOORING AREA NOT FEDERALLY MAINTAINED
- MOORING AREA FEDERALLY MAINTAINED
- TRANSIENT ANCHORAGE FEDERALLY MAINTAINED
- NAVIGATIONAL BUOY
- LIMIT 5 MPH NO WAKE ZONE

Warwick Cove Federal Mooring Area No. 3	
No.	State Plane Coordinates
M	N 221536.28, E 529539.02
N	N 220723.00, E 529055.00
O	N 221025.27, E 528885.78
P	N 221540.87, E 529192.64

City of Warwick

Harbor Management Plan

Figure 4 – Warwick Cove

May 1996